


Figure 3



Installation Instructions

- 1. Locate your AirPrime unit that is typically installed within the pump enclosure in the upper area.
- 2. Verify that your AirPrime unit has the required 1/2" NPT port as shown in Figure 3 on Page 1.
- 3. Verify that the AirPrime control location on the pump panel has the additional height available to accommodate the gauge. Refer to **Figure 4** below for the dimension requirements.
- 4. Remove the Stainless Steel pipe plug that sealed the $\frac{1}{10}$ " NPT port.
- 5. Install the 90° brass elbow with male threads that was supplied with the conversion kit. Direct the elbow towards the pump panel.
- 6. Locate the AirPrime control on the pump panel.
- 7. Disconnect the wiring harness connection at the rocker switch.
- 8. Peel back the gold label to expose the mounting screws. Remove the screws and take the entire assembly off of the pump panel.
- 9. Depress the clips at the top and bottom of the rocker switch and remove the switch from the front of the panel.
- 10. Locate position for the gauge and drill the 2.38" diameter hole in the pump panel as shown in Figure 4 below.
- 11. Install the new carrier bezel supplied with the conversion kit with the hardware that was removed in Step #8.
- 12. Remove the backing paper and apply the new label onto the new carrier bezel.
- 13. Install the rocker switch through the new label and carrier ensuring that the green indicator light is located at the top. Be sure that the clips engage the carrier.
- 14. Reconnect the switch to the wiring harness as it was before performing Step #7.
- 15. Install the elbow fitting with female pipe thread to the back of the lift gauge pictured in **Figure 5**. Insert the lift gauge through the new carrier and secure the U Clamp shown in **Figure 5** to the back of the pump panel with the threaded studs attached to the back of the gauge and nuts. Ensure that the gauge is straight prior to tightening. This clamp secures the upper portion of the carrier to the pump panel.
- 16. Finally, connect a ¼" tubing line of suitable length from the swivel push-to-connect fitting on the AirPrime installed in **Step #5** above to the push-to-connect fitting at the back of the lift gauge, as installed in **Step #15** above. **Note**: Push to connect fittings work best when the tubing is cut square and is free of burrs. Ensure that the tubing is installed as to avoid any contact with metal that may rub and cause abrasion.



Trident Emergency Products, LLC 2940 Turnpike Drive | Suite #9 | Hatboro, Pennsylvania 19040



215-293-0700 A 215-293-0701 sales@tridentdirect.com Revised 08/12/2015



AirPrime Conversion Kit Lift Gauge Compatibility Check

Adding a Lift Gauge to an Existing AirPrime Unit



Applies to the following kits:

Kit #	Description
27.005.4	Manual AirPrime Gauge Conversion Kit
27.005.5	Automatic AirPrime Gauge Conversion Kit
27.005.6	Manual to Auto with Gauge Conversion Kit


Is it possible to upgrade your AirPrime system to include a Lift Gauge?

Yes... Provided that your primer is equipped with the port pictured below.

Locate your AirPrime unit within your pump enclosure and visually inspect for the 1/8" NPT port sealed with a pipe plug.



1/8" NPT Connection to Lift Gauge.



Trident Emergency Products, LLC 2940 Turnpike Drive | Suite #9 | Hatboro, Pennsylvania 19040 USA 215-293-0700 🗏 215-293-0701 sales@tridentdirect.com

The